

## Dräger PARAT® 1200 Donning Poster

D-2619-2021



D-44715-2021

Open the cover of the case. The anti-tamper seal breaks automatically.



D-44736-2021

Remove the unit from the case and remove the nose clip from its holder on the filter.



D-44773-2021

Press the mouthpiece-tabs together and insert the mouthpiece into your mouth, holding it in place with your teeth and your lips around it.



D-44779-2021

Open the nose clip by pulling it apart ...



D-44793-2021

... and position it on your nose so that it closes your nostrils.



D-44809-2021

Leave the contaminated area immediately.